

# AR BUTTSTOCK RAIL

## Installation instructions



1. Remove butt plate from LUTH-AR stock by removing buttplate adjustment thumb screw and pulling it out of the rear of the stock.
2. Install AR-BUTTSTOCK RAIL with supplied 8-32 x 1/2" screw into the rear sling loop boss and tighten.
3. Reinstall the rear butt plate.
4. The supplied sling swivel stud may be installed into the 10-32 threaded hole in the rear of the rail to allow for a sling attachment point.

